



PART NUMBER: **F1130CMB**

PRODUCT: **LED Bumper Mount**

APPLICATION: **2011-2013 Ford
F250/350**

Parts Included:	Qty
LED Mounting Bracket	1
Hardware Pack:	1
M8x20 Button Head bolt	4
M8 washer	4
M8 Speed Clip	4



INSTALLATION:

Step 1: Locate the four mounting holes inside the center bumper opening. There will be two upper in the bumper and two larger in the outer – rearward locations. Remove plastic license plate frame by lifting up and out on the bottom tabs and pinching the two upper tabs together and removing.

Step 2: Insert the supplied m8x20 speed clips into these locations. **Note:** (If the vehicle is equipped with the block heater, it will be necessary to remove and relocate the plastic loom and harness out of the way.) You can use the small holes in the bumper on either side.

Step 3: Align the tabs on the **F1126CMB** bracket with the speed clips installed in the bumper. Loosely tighten using the supplied M8x20mm Button heads and flat washers. Do not fully tighten bracket until light bar has been installed.

Step 4: Mount light/lights into the Multi-mount bracket, leaving loose until final adjustment have been made.

Note: Our patent pending Multi-mount channel system will allow you to create multiple configurations of LED light bar and LED lights.

Step 5: Once lights and brackets have been adjusted into position, tighten all hardware. Refer to light manufactures wiring specs for install.

