



Installation Instructions

Wire Mesh Grille

14 Chevy Silverado 1500

Part Number: C14MG2

- 1 – Grille (2 pieces)
- 22 – L Brackets
- 22 – M4*15mm Phillips
- Screws 44– M4 Flange Nuts



Figure 1 – Included Hardware

TOOLS REQUIRED

- Phillips Screwdriver
- 4mm Wrench

INSTALLATION INSTRUCTIONS

1. Inspect product and check components with items listed above.
2. Pop Hood, remove plastic shroud at the top and set fasteners aside.
3. **Optional:** Using factory instructions, remove the entire front grille shell (as pictured in all Figures).
4. Attach 90° L Brackets to the screws on the grille, secure them with flange nuts.
5. Position the Grille onto grille shell cavity (Figure 2).
6. Mark locations for drilling on the shell through the other hole on the “L” brackets, then remove the brackets and drill holes on these locations.



Figure 2 – Front View of positioning Grille

7. Attach the Grille to the shell by inserting the screws through the holes of L Brackets and the holes on the shell, and then secure them with Flange Nuts provided (Figure 3).



Figure 3 – Rear view of vehicle's shell; Grills attached with Metal Brackets and Flange Nuts

8. Reinstall the plastic shroud with the fasteners removed in Step 2.



Installation Instructions

Wire Mesh Grille

14 Chevy Silverado 1500

Part Number: C14MG2

You will need to cut out portions of your OEM grille in order to install this part.

- Make sure shell is placed on a clean surface
- Use the M1 grille to determine the appropriate parts of the OEM grille shell that will need to be cut out
- Most applications require a lip to be left on the grille shell in order to attach the included brackets
- Tape off all areas that will be cut to protect the finish of the grille shell
- Use extreme caution when cutting or drilling
- Its recommended to cut a little large and then trim access where needed
- Clean all cuts with a file
- Once cut, check fitment of grille and brackets to determine if more of the shell needs to be cut out

Products Licensed to N-FAB Inc. by Fichter Designs are protected by US Patent Law and International Copy Right Law. Protected Patents include US Patent #6588783, #6874801, #7416202. Other patents and continuances pending. N-FAB product configurations also protected by International Trade Dress Law. All Designs and Patent infringements will be prosecuted to the full extent of the law.

For Technical Support. Please Call 281-880-6322